

## ULTRA **EVA** 3mm Underlayment

## Specifications:

Name: ULTRA EVA

Color: Silver and Black

Type: Sound + Vapor Barrier

Construction: Ethylene Vinyl Acetate

High Density Foam & 0.015mm Foil

Barrier Film

Coverage: Approximately 200sqft.

Overall Thickness: 3mm

Weight per Roll: 13 lbs.

**Subfloor Compatibility**: All Types

Floor Compatibility: Eco-Engineered

Composite & Laminate

**Installation Method**: Floating

Recommended Usage: Residential &

**Light Commercial** 

STC (Sound Transmission Class): 63

IIC (Impact Insulation Class): 60

**Density**: 110kg/m<sup>3</sup>

Nominal Roll Width: 10in.

Nominal Roll Height: 40in.

This product, when properly installed and used under normal conditions, is warranted to remain resilient and functional for a period equal to the warranted life of selected Ecoessent Floors and Eternity Flooring.

The EssentiaLAY Ultra EVA underlayment provides superb sound and moisture/vapor protection. The Ultra EVA underlayment will absorb minor imperfections in the sub-floor, giving your Eco-Engineered Composite or Laminate floors a smooth, even surface to float upon.

## Installation:

- 1. **Prepare the Subfloor**. Level, repair, and make sure it is free of debris
- 2. **Begin the first row.** Place the roll on the ground with the film side down (facing the subfloor).
  - Note: the overlap of film should be positioned toward the open room and the foam will face the wall.
- 3. **Measure and cut accordingly.** The plank width will determine how many rows of flooring you will be able to install. When you reach 1ft away from the underlayment, stop and roll out a second row of underlayment.
- 4. **Begin the second row.** Unroll, measure, and cut. Place the foam side over the top of the film overlap from the previous row. Butt the edges together to create a nice seam, do not overlap.
- 5. **Tape the Seams.** Use industrial tape to adhere the seams together to make a flat & even surface
- 6. **Finish.** Continue installation in sections by repeating the steps above.

Follow Ecoessent INCORE Eco-Engineered Composite or Eternity Laminate Installation Guides for more detailed instructions.

